

KeySafe™ Pro User Guide

Pushbutton combination

P/N 10103219P1 • July 2012
© 2012 UTC Fire & Security.
All rights reserved.


Press to Remove




1




2




3



4




5




6



7



8



9




10




11



12



13



Mounting

